

Flash ROM Download mode for LA48N/W

1. F/W downloading

Please update as per following description:

- (step 1) Set "F/W Download Mode" with printer. (See below Item 2)
- (step 2) Send the data by "copy/b xxxxxxxx.hex prn" in DOS prompt
- (step 3) Please wait to finish of data transmission.
- (step 4) Power off the printer after the following "Complete Downloading Mode" is displayed.
- (step 5) Load Default: Press Pause, Protocol and Park while power cycling the printer
- (step 6) You may print a test page.

Notes

Please do not power off the printer till the following "Complete Downloading Mode" is displayed.
This Flash ROM Download mode is supported by **Parallel I/F** only.

2. Printer Function

Press keys as described in (1). This will turn the printer into "F/W Download Mode".

(1) How to enter F/W Download Mode

- (a) Power on with pushing "Pause" + "Protocol" + "LF/FF" + "LOAD"
- (b) If all is OK this LEDs "Fault", "DEC" and "Ready" are lit and the printer gets into condition of "Waiting to receive data".

(2) LED display during downloading mode

(a) LED display in the mode is as follows:

Status	LED Display			
	Fault	DEC	M1/M2	Ready
Waiting to receive data	ON	ON	OFF	ON
Receiving data	ON	OFF	OFF	ON
Deleting date	ON	OFF	OFF	OFF
Rewriting data to ROM	ON	ON	OFF	OFF
Complete Downloading Mode (Received the final data)	OFF	ON	OFF	ON
Failed to download (Received error data)	OFF	ON	ON	ON

